

How to modify the language by auto provision

This instruction describes how to modify the language by provisioning simply. Please notice that this method can only allow user to modify the language which has already been built in the software.

Operation Steps:

1. Prepare a language file which you would like to modify. Since the word list in language file will always be updated according to a certain firmware update, you need to contact Yealink FAE for the latest language file.

1. If you have finished the translation, please rename the file as “**lang+/-XXXX.txt**”.

Note: If the language you would like to change is the default language, please rename the file as “**lang+XXXX.txt**”. If the language isn't the default language, please rename the file as “**lang-XXXX.txt**”.

Followed are the existent language names in the software.

- lang+English.txt
- lang-French.txt
- lang-German.txt
- lang-Italian.txt
- lang-Portuguese.txt
- lang-Turkey.txt
- lang-Chinese_S.txt
- lang-Chinese_T.txt
- lang-Polish.txt
- lang-spanish.txt

2. Put the file to the .cfg file as followed.

```
[ Lang ]  
path = /tmp/download.cfg  
server_address =
```

For example:

```
[ Lang ]  
path = /tmp/download.cfg  
server_address = http://10.1.4.40:88/lang-Portuguese.txt
```

3. Then you can do the provision to upload the .cfg file to enjoy your modified translations.