

TECH ARTICLE

Date: 13/11/2007

Revision Date (6 months max): N/A

Topic / Issue: Configuration of Access Point for Wireless Bridge Mode

Written By: Scott Young

To configure your GL2422AP-S Access Points to run in Wireless Bridge Mode please follow these instructions:

Please ensure that you are running firmware version 03.01.0B or later.

Select Wireless Bridge on each Access Point and then enter LAN MAC Address of the other Access Point in the Remote Bridge MAC option.

Make sure that all IP Settings are correct. (DHCP Server is off, and IP address of each Access Point is different).

Make sure that both Access Points are using the same ESSID, Channel and WEP key.

Summary:
(If required)