

TECH ARTICLE

Date: 12/11/2007

Revision Date (6 months max): N/A

Topic / Issue: Configuring RSTP on the EF-24M02G

Written By: Scott Young

To configure RSTP successfully on the EF-24M02G the following must be configured or RSTP will not function correctly

1. Configure your module slots to the correct module type (EFM-04SC, EFM-08TX etc.).

NOTE: If no modules are in use please be sure to configure that slot as "no module".

2. In the port configuration option configure any ports that are not in use to be "disabled".

NOTE: If the EF-24M02G is not fully loaded with modules the rest of the ports including the GBIC ports must be disabled. Otherwise these floating ports will influence the behavior of RSTP and will result in a busy CPU which will cause the EF-24M02G to function at a slow rate.

3. Enable RSTP on EF-24M02G.

Summary:
(If required)