

TECH ARTICLE

Date: 14/11/2007

Revision Date (6 months max): N/A

Topic / Issue: Resetting the Lockdown-SME to default configuration

Written By: Scott Young

Hold in the reset button for more than 5 seconds to reset the Lockdown-SME back to factory default.

Summary:
(If required)