

Yealink IP Phones Power Consumption Table

5V	Status	SIP-T38G	SIP-T32G	SIP-T28P	SIP-T26P	SIP-T22P	SIP-T20P	SIP-T10TP	EXP39	EXP38	SIP-T28P + N x EXP38
Power by Adapter	Standby Mode	3.00W	2.50W	1.59W	1.56W	1.48W	1.39W	1.59W	0.90W	0.40W	1.59+Nx0.40W
	Max	4.20W	3.50W	2.57W	2.57W	2.56W	2.56W	2.57W	1.00W	0.68W	2.57+Nx0.68W
PoE	Standby Mode	3.00W	2.50W	1.59W	1.56W	1.48W	1.39W	1.59W	0.90W	0.40W	1.59+Nx0.40W
	Max	4.20W	3.50W	2.57W	2.57W	2.56W	2.56W	2.57W	1.00W	0.68W	2.57+Nx0.68W

Note: SIP-T38G/SIP-T28P/SIP-T26P allows to connect up to 6 EXP38. But if you use more than 3, you need to connect an additional power adapter to anyone of them.